



STROBE / SOUNDER INTERFACE

INSTALLATION & CONFIGURATION MANUAL

Documentation Feedback

Your feedback helps us keep our documentation up to date and accurate. If you have any comments or suggestions about our printed manuals you can email us.

Please include the following information:

- Product name and version number (if applicable)
- Manual part number and revision (found on the front cover)
- Page number
- Brief description of the content you think should be improved or corrected
- Your suggestion for how to correct/improve documentation

Send email messages to:

techpubs@notifier.com.au

Please note this email address is for documentation feedback only. If you have any technical issues, please contact your nearest branch for technical support.

Table of Contents

Section 1 About this Manual.....	2
1.1. Notes, Cautions and Warnings.....	2
1.2. Related Documentation.....	2
Section 2 System Overview	3
2.1. Introduction.....	3
2.2. Features	3
2.3. Specifications.....	3
2.4. System Diagram.....	3
2.5. Available Kits	4
Section 3 Installation.....	5
3.1. Module Mounting	5
a. <i>Single module</i>	5
b. <i>'Double Stacking'</i>	6
3.2. Connection to DA series BOWS.....	6
3.3. Connection to Notifier 10W, 25W, 50W or Legacy 120W BOWS.....	7
3.4. Connection to a CIE.....	7
3.5. Connection to Sounder or Strobe devices	8
Section 4 Operation.....	9
4.1. Display module indicators	9
4.2. Normal Operation	9
4.3. Fault Operation	9
4.4. Alarm Operation	9
a. <i>Manual Dual-stage operation</i>	9
b. <i>Automatic (timer enabled) Dual-stage operation</i>	10
Section 5 Configuration	11
5.1. Enabling and setting Level 1 (alert) to Level 2 (evac) delay time.....	11
5.2. Setting the polarity of the Stage 1 (alert) and Stage 2 (evac) inputs....	12

Section 1 About this Manual

1.1. Notes, Cautions and Warnings

This manual contains notes, cautions and warnings to alert the reader as follows:



NOTE: Supplement information for a topic such as tips and references.



CAUTION: Information about procedures that could cause programming errors, runtime errors, or equipment damage.



WARNING: Indicates information about procedures that could cause irreversible equipment damage, irreversible loss of programming data or personal injury.

1.2. Related Documentation

Related documentation:

Title	Document Number
DA Series BOWS – Installation & Programming Manual	DOC-01-004

Table 1-1 Related Documentation

Section 2 System Overview

2.1. Introduction

The Notifier Strobe/Sounder Interface Module provides a high current monitored output to strobes and sounders. This output is capable of reversing polarity for connection to dual level devices ie alert to evacuate operation.

2.2. Features

- 2 level operation for alert and evacuation signals
- Configurable for automatic (via timer) or manual (via inputs) level 1 to level 2 changeover
- Ability to change alarm levels on high or low signal input
- Compatibility with Notifier legacy and DA-series building occupant warning systems
- High power 5A output

2.3. Specifications

- Operating Voltage Range: 20.6VDC to 27.6VDC
- Current Consumption @ 24VDC nominal
 - ✓ Normal/Quiescent: 25mA
 - ✓ Alarm: 90mA (+ strobe & sounder load)
- For use indoors in a dry location
- Form-C Relay Outputs
 - ✓ System Fault – Normally Energised
 - ✓ Relay Contact Ratings: 1A @ 30VDC (resistive)
- Strobe / Sounder Output
 - ✓ Output Rating: 5A @ 24VDC nominal – with Fuse F1
 - ✓ End-of-Line-Resistor: 1.8K Ohm 1 Watt
- Inputs
 - ✓ Alert and Evac

2.4. System Diagram

A block diagram of a typical Strobe/Sounder interface module is provided in Figure 2-1




Figure 2-1 – Typical Strobe/Sounder Interface setup

2.5. Available Kits

The following kits are available from Notifier:

Title	Notifier Part #
Notifier Strobe/Sounder Interface Module	ASY-01-002

Table 2-1 Available Kits

Section 3 Installation



WARNING: Remove all power sources to equipment while connecting electrical components. Leave the external, main power breaker OFF until installation of the entire system is complete.

3.1. Module Mounting

a. Single module

The strobe & sounder interface can be mounted by one of the following methods

- in a standard chassis assembly using the supplied adapter plate
 - on a standard relay expansion slot (outer 4 holes)
1. Mount the module fitted to the adapter plate into a standard chassis expansion slot as shown in Figure 3-1




Figure 3-1 – Module mounting onto a standard chassis expansion slot

or

2. Remove the module from the adapter plate and mount PCB onto a standard relay expansion slot as shown in Figure 3-2




Figure 3-2 – Module mounting onto a standard relay expansion slot

b. 'Double Stacking'

The Sounder/Strobe interface can be 'double stacked' by mounting the top module to the lower module using the inner 4 mounting points as shown in Figure 3-3 using the supplied stand-offs and M3 flanged nuts. It is not required to break off outer edges of the PCB, however it may be preferable to allow access to the lower PCB mounting points.




Figure 3-3 – “Double Stacked” using inner mounting holes

3.2. Connection to DA series BOWS

Connect the sounder and strobe interface module to DA-BOWS as shown in Figure 3-4 using a modified 6 way cable. The sounder/strobe interface should be setup for negative alert and evacuation trigger see section 5.2. See the DA-BOWS manual for more information on its operation.




Figure 3-4 – DA BOWS connection

3.3. Connection to Notifier 10W, 25W, 50W or Legacy 120W BOWS

Connect the strobe card to BOWS as shown in below figure. The sounder/strobe interface should be setup for positive alert and evacuation trigger see section 5.2



NOTE: If the 'Alert' stage is not required then this connection may be omitted.




Figure 3-5 – Strobe/Sounder interface to 10W, 25W, 50W and Legacy 120W connection

3.4. Connection to a CIE

Connect the strobe card to FIP as shown in below figure. The sounder/strobe interface should be setup for positive alert and evacuation trigger see section 5.2



NOTE: If the 'Alert' stage is not required then this connection may be omitted.




Figure 3-6 – Strobe/Sounder interface to CIE connection

3.5. Connection to Sounder or Strobe devices

Connect the sounder or strobe devices to the output as shown in Figure 3-7. The sounder/strobe interface should be setup for positive alert and evacuation trigger see section 5.2.

The End-of Line device should be a 1K8, 1 Watt resistor.



NOTE: If the 'Alert' stage is not required then this connection may be omitted.




Figure 3-7 – Sounder and/or strobe connection

Section 4 Operation

4.1. Display module indicators

The strobe and sounder interface module has five LED indicators on the PCB to indicate the condition of the output

Normal (NORM)

This is a green indicator which illuminates if the output is not in fault, ie the 1k8 end-of-line resistor is present.

Level 1

This red indicator illuminates when the system is Level 1 or higher alarm which occurs when;

- a) The Level 1 (*AL*) input is active.
- b) The Level 2 (*EV*) input is active

Level 2

This red indicator illuminates when the system is Level 2 alarm which occurs when;

- a) The Level 1 (*AL*) input is active and Level 1 to Level 2 delay timer has expired.
- b) The Level 2 (*EV*) input is active

Open Circuit (O/C)

This yellow indicator illuminates when open circuit wiring fault exists on the strobe/sounder output. It will also illuminate if the fuse 1 is blown.

Short Circuit (S/C)

This yellow indicator illuminates when short circuit wiring fault exists on the strobe/sounder output.

4.2. Normal Operation

With no faults or inputs active on the module the *NORM* indicator will be illuminated with all other indicators off. The sounder/strobe module should measure approximately 0.8V

4.3. Fault Operation

A fault on the system will cause the following;

- Either the open circuit or short circuit fault indications illuminate to identify the cause of the fault(s).
- The normal (*NORM*) indicator will turn off
- The Fault relay output to de-activate.



NOTE: Fault monitoring is not active when the module outputs are in either level 1 or level 2 alarms.

4.4. Alarm Operation

a. Manual Dual-stage operation

The activation of the Level 1/alert (*AL*) input event by a CIE or building occupant warning system will cause the following;

- *Level 1* indicator on the module will illuminate.
- The Strobe/Sounder output will activate in alert mode see Table 4-1 for polarity details

The activation of the Level 2/evac (*EV*) input event by a CIE or building occupant warning system will cause the following;

- *Level 1* and *Level 2* indicators on the module will illuminate.
- The Strobe/Sounder output will activate in evacuation mode see Table 4-1 for polarity details

b. Automatic (timer enabled) Dual-stage operation

The activation of the Level 1/alert (*AL*) input event by a CIE or building occupant warning system will cause the following;

- *Level 1* indicator on the module will illuminate.
- The Strobe/Sounder output will activate in alert mode see Table 4-1 for polarity details

The delay timer expiring will cause the following;

- *Level 1* and *Level 2* indicators on the module will illuminate.
- The Strobe/Sounder output will activate in evacuation mode see Table 4-1 for polarity details

	Level 1 alarm (alert)	Level 2 alarm (evac)
Output A	+ 24V	0 V
Output B	0 V	+ 24V

Table 4-1 Output polarity

Section 5 Configuration

5.1. Enabling and setting Level 1 (alert) to Level 2 (evac) delay time

To enable the automatic stage changeover time, ensure link is fitted on JP 1 as shown in Figure 5-1




Figure 5-1 – Auto/Manual DIP switch location

The automatic stage changeover time can be adjusted by variable resistor R1 see Figure 5-2, turn adjustment clockwise to increase delay and counter-clockwise to decrease the delay.




Figure 5-2 – Delay time setting location



NOTE: The alert to evacuation delay time is only enabled when the evacuation delay is configured.

5.2. Setting the polarity of the Stage 1 (alert) and Stage 2 (evac) inputs

The input polarity for the Evac input is set by J1 and the Alert input polarity is set using J2 as shown in Figure 5-3 and Table 5-1




Figure 5-3 – Configuration of input polarity.

	Positive (24V) input	Negative (0V) input
J1 – Evac input polarity	Fit link on pins 1 & 2	Fit link on pins 2 & 3
J2 – Alert input polarity	Fit link on pins 1 & 2	Fit link on pins 2 & 3

Table 5-1 Input polarity

Notes



New South Wales
(Head Office)
9 Columbia Way
Baulkham Hills NSW 2153

ph +61 (02) 9899-4155
fax +61 (0)2 9899-4156

Queensland
24 Potts Street
East Brisbane, QLD 4169

ph +61 (0)7 3391 5777
fax +61 (0)7 3391 5800

Victoria
32 Lambert Street
Richmond, VIC 3121

ph +61 (0)3 9421 5552
fax +61 (0)3 9421 5553

Western Australia
Unit 4, 283 Camboon Road
Malaga WA 6090

ph +61 (0)8 9270 6555
fax +61 (0)8 9270 6556

New Zealand
264 Mt Eden Road
Auckland

ph +64 (0)9 623 5050
fax +64 (0)9 623 5060