PRODUCT DATA SHEET
Warning Signs

PRODUCT DESCRIPTION

Solid state dual level LED Warning Signs, ideal for use with gaseous protection systems. Static warning signs also available.

Unique LED design provides for low current consumption with maximum brightness.

Signs can have external sounders and remote mute buttons.

Signs can be configured as 2 wire or 3 wire, in 2 wire mode dual level alarms are achieved by simply reversing polarity on the input.

TECHNICAL SPECIFICATIONS

Operational Voltage	18Vdc to 28Vdc
Power Consumption @ 24Vdc	**Level 1:** 55mA **Level 2:** 140mA (100mA when muted)
Dimensions	315mm W x 190mm H x 73mm D
IP Rating	IP50 (IP54 with gasket fitted)
Environmental	-10°C to +55°C dry heat +40°C @ 93% relative humidity
LED Light Colour	**WARN-S:** Red **WARN-SYS (Extinguishing System Inoperative):** Yellow

Weatherproof:

Dimensions	295mm W x 200mm H x 70mm D
IP Rating	IP65
Construction	UV Protected PVC

NSW
18-20 Brookhollow Ave
NORWEST 2153
02 8850 2888
sales@firesense.com.au

VIC
Unit 4, 297 Ingles St
PORT MELBOURNE 3207
03 9646 4557
salesvic@firesense.com.au

QLD
Unit 2, 225 Queensport Rd North
MURARRIE 4172
07 3890 8842
salesqld@firesense.com.au

PRODUCT DATA SHEET
Warning Signs

FACEPLATES AVAILABLE

WS-CUST*	Custom face plate. *Note: This is an indent item, lead times may apply.*
WS-DNE-GD*	“DO NOT ENTER, GAS DISCHARGED”
WS-FA-DNE*	“FIRE ALARM, DO NOT ENTER”
WS-FA-EA*	“FIRE ALARM, EVACUATE AREA”
WS-FDC	“FIRE DOOR CLOSING”

* The above faceplates are also available in weatherproof versions.

STATIC WARNING SIGNS AVAILABLE

WS-STATIC-FDC	“FIRE DOOR CLOSING”
WS-STATIC-SFD	“SLIDING FIRE DOOR”

CURRENT RELEASE



Jumper No.			Description
JP-1	1-2	Dual Level	Top rows LEDs will be ON at Level 1 Alarm All LEDs will be ON at Level 2 Alarm
	2-3	Single Level	All LEDs will be ON at both Level 1 & 2 Alarm
JP-2	1-2	Continuous	LEDs permanently ON. Internal buzzer outputs continuous tone.
	2-3	Flashing	LEDs flash at the approximate rate of 2.3 Hz. Internal buzzer outputs tone matching the flashing LEDs.
JP-3	1-2	Enable Sounder	External Sounder will be active at both Level 1 & 2 Alarm
JP-4	1-2	Enable Buzzer	Internal buzzer will be active at both Level 1 & 2 Alarm
JP-5	1-2	Disable Ext-Mute	Disable external mute for both internal buzzer and external sounder.

Table 1: Jumper Configuration

NSW
18-20 Brookhollow Ave
NORWEST 2153
02 8850 2888
sales@firesense.com.au

VIC
Unit 4, 297 Ingles St
PORT MELBOURNE 3207
03 9646 4557
salesvic@firesense.com.au

QLD
Unit 2, 225 Queensport Rd North
MURARRIE 4172
07 3890 8842
salesqld@firesense.com.au

www.firesense.com.au

PRODUCT DATA SHEET
Warning Signs

CONNECTION INFORMATION

Model 2001 Gas Card



Model 922 Gas Card



NSW
18-20 Brookhollow Ave
NORWEST 2153
02 8850 2888
sales@firesense.com.au

VIC
Unit 4, 297 Ingles St
PORT MELBOURNE 3207
03 9646 4557
salesvic@firesense.com.au

QLD
Unit 2, 225 Queensport Rd North
MURARRIE 4172
07 3890 8842
salesqld@firesense.com.au

www.firesense.com.au